


Каталог запчастей двигателя LIFAN 178F

Item	Part	Qty	名称	Description
1	18000	1	消声器总成	Muffler
2	GB/T5789-86	2	螺栓M8×22	Bolt M8×22
3	GB/T6170-2000	2	螺母M8	Nut M8
4	GB/T93-87	2	弹垫8	Ball washer 8
5	GB/T97.1-85	3	平垫8	Flat washer 8
6	13411	1	活塞环(一)	Piston ring (I)
7	13412	1	活塞环(二)	Piston ring (II)
8	13420	1	油环组合	Scraper ring set
9	GB893.1-86	2	挡圈21	circlip 21
10	13311	1	活塞	Piston
11	13312	1	活塞销	Piston pin
12	13121	1	连杆	Connecting rod shank
13	13131	2	连杆轴瓦	Connecting rod shafting
14	13122	1	连杆盖	Connecting rod cap
15	13123	2	连杆螺栓	Bolt
16	GB/T5789-86	11	螺栓M6×12	Bolt M6×12
17	15112	1	机油泵盖	Cover, oil pump
18	GB/T3452.1-2005	1	O型圈34×1.8	O-ing34×1.8
19	15100	1	机油泵总成	Oil pump assembly
20	GB/T9877.1-2008	1	油封SG35×50×10	Oil seal (35×50×10)
21	GB/T5789-86	15	螺栓M8×33.5	Bolt M8×33.5
22	GB/T119.1-200	1	销3m6×16	Set pin 3m6×16
23	GB/T16674.2-2004	1	螺栓M10×1×12	Bolt M10×1×12
24	11200	1	曲轴箱盖组合	Crankcase cover
25	GB/T97.1-85	1	铝垫10	Aluminium washer
26	15200	1	机油滤清器总成	Crankshaft Filter-cover
27	GB/T3452.1-2005	1	O型圈20×2.52	O-ing20×2.52
28	15511	2	机油尺	Dipstick
29	GB/T3452.1-2005	2	O型圈19×3.55	O-ing19×3.55
30	11217	1	滑动轴承	Bearing
31	GB/T119.1-2000	2	定位销8m6×12	Set pin8m6×12
32	GB/T276-94	1	滚动轴承6206	Bearing 6206 P5
33	15120	1	机油泵从动齿轮组件	Engine oil pump driven gear subassembly
34	15215	1	进油导管	Enter oil trachea
35	15123	1	机油泵从动齿轮滑套	Engine oil pump driven gear slide sheath
36	GB/T290-98	2	滚针轴承HK081410	Roller bearing
37	26290	1	杠杆轴油封组件	Bearing
38	26300	1	拨叉组合	Dial assembled
39	11114	1	曲轴箱垫片	Gasket, crankcase
40	13113	1	正时主动齿轮	Timing driving gear
41	GB/T276-94	2	滚动轴承6202	Bearing 6202 P5
42	13116	1	平衡轴	Equilibrium shaft

43	GB/T1096-2003	2	键5×7	Key 5×7
44	13151	2	平衡轴齿轮	Balancing shaft
45	GB/T5789-86	2	螺栓M6×18	Bolt M6×18
46	16914	1	下导风罩衬套	Below guide bush
47	19123	1	下导风罩减震胶套	Below guide damping pastern
48	19121	1	下导风罩（一）	Below guide
49	19122	1	下导风罩密封胶条	Below guide airproof pastern
50	13111	1	曲轴	Crankshaft
51	GB/T1096-2003	2	键5×12	Key 5×12
52	GB/T308-2002	1	钢球1/4G200	Steel ball
53	14119	1	凸轮轴正时齿轮	Timing driving gear
54	GB/T1096-2003	1	键4×12	Key 4×12
55	14210	2	推杆组件	Pusher
56	14315	2	挺柱	Tappet
57	GB/T290-98	1	滚针轴承HK1512	Roller bearing
58	GB/T5789-86	1	螺栓M8×12	Bolt M8×12
59	11151	1	轴承止推片	Bearing stop patch
60	GB/T276-94	1	滚动轴承6307	Bearing 6307 P5
61	11155	2	气缸头连接螺柱（一）	Cylinder head connect Bolt
62	11152	1	矩形密封圈	Rectangle pressurize loop
63	GB/T93-87	5	弹垫6	Ball washer 6
64	GB/T6170-2000	5	螺母M6	Nut M6
65	GB/T97.1-85	6	平垫6	Flat washer 6
66	28511	各1	喷油泵垫片 ϕ 0.1~0.5	Sprinkling pump adjust washer
67	28513	1	观察孔密封板	Observe hole airproof board
68	28512	1	观察孔密封垫片	Observehole airproof washer
69	11160	1	油量控制器组件	Oil quantity controller subassembly
70	14111	1	凸轮轴	Cam shaft
71	26200	1	转速控制臂组件	Regulating arm Assy
72	28500	1	喷油泵总成	Sprinkling pump assembly
73	GB/T5789-86	3	螺栓M6×14	Bolt M6×14
74	26200	1	调速支架组合	Regulating mount
75	26117	1	复位弹簧	Back spring
76	26215	1	调速弹簧	Regulating spring
77	26232	1	扭簧	wrest spring
78	11115	2	放油螺塞	Drain plug
79	11116	2	放油螺塞垫圈	Washer
80	11100	1	曲轴箱组合	Crankcase
81	GB/T9877.1-1988	1	油封SG30×45×8	Oil seal (30×45×8)
82	23200	1	反冲起动器组合	Recoil starter
83	19224	4	风扇罩减震胶套	an hood damping pastern
84	19225	4	风扇罩衬套	Fan hood bush
85	GB/T5789-86	4	螺栓M6×25	Bolt M6×25
86	19211	1	风扇罩	Fan hood
87	19223	1	风扇罩密封胶条	Fan hood airproof pastern

88	GB/T97.1-85	2	平垫10	Flat washer10
89	23316	1	起动套	Starting flange
90	23317	1	飞轮螺母	Nut
91	23319	1	飞轮螺母垫圈	Flywheel nut washer
92	23311	1	飞轮	Flywheel
93	17100	1	空滤器总成	Air cleanr assembly
94	GB/T900-88	4	螺柱AM6×26 (总长)	Bolt M6×26
95	17113	1	空滤器垫片	Air cleanr washer
96	17214	1	空滤器连接盘	Air cleanr linker
97	12159	1	起动机盖板	Starter cover board
98	GB/T5783-2000	2	螺栓M10×16	Bolt M10×16
99	11156	2	气缸头连接螺柱 (二)	Cylinder head connect Bolt
100	12121	1	气缸头密封垫片	Gasket, cylinder head
101	17221	1	空滤器连接盘垫片	Air cleanr linker washer
102	11153	2	喷油泵双头螺栓 (一)	Gasket, cylinder head
103	GB/T900-88	2	螺柱AM6×30 (总长)	Bolt M6×30
104	14411	1	进气门	Intake valve guide
105	14412	1	排气门	Exhaust valve guide
106	12151	1	气缸头进气管	Cylinder head ir intake pipe
107	17219	1	进气口垫片	Intake pipe washer
108	GB/T900-88	2	螺柱AM6×67 (总长)	Bolt M6×67
109	12100	1	气缸头组合	Cylinder head assy
110	GB/T899-88	2	螺柱AM8×32 (总长)	Bolt M8×32
111	18215	1	排气口垫片	Exhaust gasket
112	GB/T900-88	2	螺柱AM6×62 (总长)	Bolt M6×62
113	12157	4	气缸头螺母垫片	Cylinder head nut washer
114	12156	2	气缸头螺母	Cylinder head nut
115	GB/T119.1-200	1	销4m6×8	Set pin 4m6×8
116	12158	1	隔热套	Heat insulation sheath
117	28712	各1	喷油器调整垫片 δ 0.1-0.5	Sprinkling machine adjust washer
118	28700	1	喷油器总成	Sprinkling machine assembly
119	28711	1	喷油器压板	Sprinkling machine seasaw
120	14416	2	气门顶帽	Cap
121	12155	2	气缸头盖形螺母	Gasket, cylinder head cover
122	14417	2	气门弹簧下座	Spring seat
123	14430	2	气门油封组件	Valve Oil seal subassembly
124	14414	2	气门弹簧	Valve spring
125	14415	2	气门弹簧座 (二)	Intake valve
126	14418	2	气门锁夹	Split pin
127	14330	1	摇臂支座组件	Rocker abutment subassembly
128	GB/T5789-86	2	螺栓M8×45	Bolt M8×45
129	12212	1	气缸头盖密封圈	Gasket, cylinder head cover
130	12200	1	气缸头盖组合	Cylinder head cover
131	GB/T5789-86	2	螺栓M6×60	Bolt M6×60
132	16500	1	燃油箱组合	Fuel filler cap Assy

133	28610	1	高压油管组件	High-handed vita subassembly
134	16640	1	燃油开关组件	Fuel cock
135	GB/T3452.1-2005	1	O型圈13×2	O-ring13×2
136	16664	1	燃油过滤器密封圈	Fuel filter washer
137	16660	1	燃油过滤器组件	Fuel filter parts
138	16643	1	燃油开关密封圈	Fuel switch washer
139	16580	1	燃油箱下支架组件	Fuel filler cap belowbracket subassembly
140	16911	4	油箱减震垫	Fuel tank cushion
141	GB/T16674.2-2004	1	螺栓M12×1.25×14	Bolt M12×1.25×14
142	16671	1	油箱放油螺栓垫片	Oil box discharge bolt washer
143	16610	1	过滤杯组件	Filter cup subassembly
144	16400	1	燃油箱盖组合	Fuel filler cap
145	GB/T6177.1-2000	8	螺母M6	Nut M6
146	16548	1	燃油箱支架紧固螺栓	Fuel filler cap bracket bolt
147	11154	1	喷油泵双头螺栓（二）	Gasket, cylinder head
148	26311	各1	拨叉调整垫片	Dial adjust washer
149	16543	1	燃油箱支架	Fuel filler cap bracket
150	16623	1	出油管（二）	Outlet pipe
151	16624	2	油管夹（二）	Pipe clamp
152	16622	2	油管夹（一）	Pipe clamp
153	16621	1	出油管（一）	Outlet pipe



178F爆炸图